

Technical Manual

Votani NewX1 MAX



Contents

1. Electronic components	1
1.1 Specification	3
1.1.1 Controller	3
1.1.2 Speed Sensor	3
1.1.3 Motor	4
1.1.4 HMI	5
1.1.5 Battery	6
2. Operation	7
2.1 Battery	7
2.1.1 Start usage	7
2.1.2 Charge	8
2.1.3 Important safety notes for battery charging	9
2.2 HMI	10
2.2.1 Display information	10
2.2.2 Function key description	11
2.2.3 Function settings	13
2.2.4 Message	17
2.3 eBrake	18

3. Disassembling components	19
3.1 Drive assembly	19
3.2 Motor	20
3.3 HMI	21
3.4 Shimano components	22
4. Manual of EB Service interface	25
4.1 Resource introduction	25
4.2 Install program	28
4.2.1 PL2303 driver setup	28
4.2.2 Component installer	33
4.3 Controller	37
4.3.1 Connect to controller with Diagnosis tool	37
4.3.2 Firmware update	40
4.3.3 Monitor	46
4.3.4 Sensor signal count	46
4.3.5 Wheel setup	47
4.3.6 Angle sensor calibration	47
4.3.7 Toque sensor calibration	47
4.3.8 Full test	49

4.4 HMI 52

4.4.1 Connect to HMI with Diagnosis tool.....52

4.4.2 Firmware update55

4.4.3 LCD setting61

4.5 Battery 62

5. Trouble shooting..... 65


5.1 Error or warning alert..... 65

5.2 Procedure 69

1. Electronic components



1. HMI function button
2. Front light
3. Motor
4. Controller
5. Battery indicator and charge port
6. Battery lock
7. Rear light
8. Speed sensor



1.1 Specification

1.1.1 Controller



Model	A-Type
Operating temperature	-15°C to 50°C (5°F to 122°F)
Storage temperature	-15°C to 100°C (5°F to 212°F)
Storage humidity	10% to 85%
ROHS	Confirms the ROHS of PTC
Function	1. Over voltage protection 2. Over current protection 3. Stall protection 4. Speed limitation 5. UART communication 6. BLDC driver with hall 7. Battery communication
Output power	250W
Operating voltage	36V regular (Range: 30V to 42V)
Efficiency	92%

1.1.2 Speed Sensor



Model	BigStone Speed
RPM resolution	1 Impulses / Rotation
Weight	N.A
Operating voltage	5V
Clockwise	Yes
Counterclockwise	No
Direction	Yes

1.1.3 Motor



Model	250W Mid Motor
Operating temperature	-20°C to 85°C (-4°F to 185°F)
Storage temperature	-20°C to 65°C (-4°F to 149°F)
Storage humidity	<40%
Weight	<3.8kg
ROHS	Yes
Noise	<55dB
Max RPM	80RPM
Max torque	>80Nm
Rating output	250W
Operating voltage	36V regular (Range: 24V to 48V)
Efficiency	>78%
RPM resolution	12 Impulses / Rotation
Operating voltage	5V
Clockwise	Yes
Counterclockwise	No
Direction	Yes

1.1.4 HMI



Model	Central LCD HMI
Active area	100 (L) x 75 (W)
Operating temperature	-15°C to 50°C
Storage temperature	-15°C to 70°C
Storage humidity	10% to 90%
Display type	LCD display
LCD / LED type	FSTN, Positive, COG
Viewing direction	6 o'clock
ROHS	Confirms the ROHS of PTC
Information	ODO, Trip, RPM, Message, Speed, Battery indicator
Assistant level	3 assistance level

1.1.5 Battery



Item	Rate performance	Remark
Battery	2150mAh	SONY
	2750mAh	LG
Typical capacity	Above 10750mAh \pm 5% (11) Above 12900mAh \pm 5% (13) Above 16500mAh \pm 5% (17)	Rate discharge capacity after rate charge
Nominal voltage	37V	
Maximum charge voltage	42.5V	CV mode charging voltage
Voltage at end discharge	31.34V	Stop discharge when anyone cell reach to $2.5 \pm 0.02V$
Max. charge current	4A	
Suggestion continuous discharge current	10A	$\leq 389W$
Suggestion maximum discharge current	12A	$\leq 555W$
END of charge condition	50mA	I min
Operation temperature	0°C to 45°C	Charge
	-10°C to 55°C	Discharge
Storage temperature	-10°C to 45°C (<1 month)	The best temperature in transport is 20°C to 25°C
	-10°C to 35°C (>1 month)	
Power consumption normal mode	$\leq 50mA$	
Sleep mode	$\leq 1mA$	
shutdown mode	$\leq 100\mu A$	


2. Operation

2.1 Battery

2.1.1 Start usage

To install the battery, please put the battery inside the cradle and push it until locked.

To remove the battery, please turn the key and pull the battery out from the cradle at the same time.



LED behaviors :

(1) Charging : **One way scrolling (from 0 to current level)**

(2) Fully charged : **LEDs all ON**

(3) Power on progress :

LED 1 – ON : 6% ~ 20%, FLASH : 0% ~ 5%

LED 2 – ON : 21% ~ 40%

LED 3 – ON : 41% ~ 60%

LED 4 – ON : 61% ~ 80%

LED 5 – ON : 81% ~ 100%

(4) Power off progress : **LED 1, 3, 5 are ON**

2.1.2 Charge

1. General use instructions

- A. Connect the cable from charger to battery, and then insert the plug.



- B. While the charger starts charging, the led shows red color.

While the charger standby or finishes charging, the led shows green color. If you are done charging, disconnect the charger from the battery before removing the power plug from power socket.



2. Charging time



The charging time depends on the remaining energy in the battery and the charger current. The acceptable charger input voltage is AC 100 - 240V ~ 4A (50 / 60Hz).

If the battery is completely discharged, you can estimate the charging time by the following calculation example :

The estimated charging time is the battery's capacity divided by the charger's current. The standard new X1 max battery is 11 Ah and the standard new X1 max charger is 4A.


Estimated charging time = $11 / 4 = 2.75$ hours

2.1.3 Important safety notes for battery charging


- Use only the battery charger delivered with the product.
- Use only dry charger, undamaged power cable and charger.
- Replace damaged power cable and charger immediately.
- Remove any possible foreign object from the charging socket, such as dusts, ice or snow before plugging in.
- Using any battery charger other than the one delivered with the product may cause overheating of the battery or even a risk of explosion.
- Deep discharging of battery may result in internal damage.
- There is a fire risk if the temperature of battery rises up to a dangerous level.
- Avoid deep discharging of battery while in use or storage.
- If not in use, the battery should be charged fully at least every 3 months.
- Do not expose the bike in a storage temperature lower than -20°C (-4°F) or higher than 60°C (140°F). Please note that the internal structure of battery may be overheated to damage due to high temperature greater than 60°C, particularly exposed to direct sunlight.
- Do not use the charger at a humid place or an ambient temperature lower than -10°C (14°F) or higher than 40°C (104°F).
- The battery and charger are maintenance-free. Do not attempt to disassemble or modify the battery or charger.
- Do not expose the battery to high voltage.
- It is advised not use battery with damaged casing.
- Do not cover the battery or the charger while charging is in progress.

2.2 HMI

2.2.1 Display information



- **Speed**
Display of current speed, and precision is decimal point one.
- **Assistant level**
There are totally 3 levels for choice when you are riding.
When the system is turned on again, it will return to "0".
With level 0 you will feel like riding a regular bike without any electrical assistance.
With level 3, it will support you the maximum power.
- **Battery capacity**
The battery sign on HMI will tell you how much capacity is left in your battery when the system is on. The following illustration shows how much power is left.




Battery capacity is 0% when the battery light flashes, please charge immediately.

2.2.2 Function key description




- Power

Make sure the battery is installed; press [Power] button to turn on/off the system.



- Light switch

Press [Light] button to turn on/off the screen backlight, front and rear light on bike.



- Assistance model setting

Press [+] or [-] button to change the output power of the motor.


- Function setting

Press and hold [i] button for 1.5 seconds to enter function selection.

- Information selection

Press [i] button to toggle the different trip information shown on screen.

For example: ODO, Trip distance, Average speed, RPM and Range distance.



【 Note 】


The "information" buttons are located in both handle bar and main display with the same function.

2.2.3 Function settings


When entering function setting mode, press [+] or [-] button to select different functions.

To enter these functions, you can press [i] button, or press and hold [i] button for 1.5 seconds to leave it.


< Function page >




Trip clear




Information rotation
display setting



Distance unit




Time setting



Information


- Trip clear



Press [+] or [-] button to clear the trip, and press [i] button to confirm.


<Note> When you clear trip, average speed will be reset.

- Information rotation display setting




Press [+] or [-] button to select "Yes" to activate it or "No" to leave, and press [i] button to confirm.

With this function enabled, the screen will show as below, and information options automatically alternates for every 2 seconds.




- Distance unit



Press [+] or [-] button to select km or mile, and press [i] button to confirm.


The speed and distance are shown in "km/h" or "mph" and "km" or "mile" respectively.

- Time setting



Change the time at the cursor, and press [+] or [-] button to change the number, then press [i] button to the next. After all the numbers have been set, press [+] or [-] button to select "O" to confirm it or "X" to re-input. Press [i] button to confirm.


- Information



Show version of HMI and controller, and press [i] button to confirm leave it.


2.2.4 Message

This message only shows when system needs to tell issues.
(Please refer to "5.1 Error or warning alert")



2.3 eBrake

When the e-brake lever is pressed, the motor will stop giving assistance and the rear light will become lighter at the same time.



3. Disassembling components

3.1 Drive assembly

A. Controller


E. M4*8L screw x 6

B. Switch key

F. Controller cable

C. M4*8L screw x 6


D. M5*8L screw x 2




Note ! Once you finish the replacement of controller, please refer to section 4.3.6 to calibrate the sensor.

3.2 Motor

A. Remove 2 M4 screws under the Mid-Motor. And then remove the Motor Cover.




B. Remove 3 M6 Bolts and disassemble the Mid-Motor.




3.3 HMI

- A. Nut M3
- B. M3*8 cap head screw x 1
- C. M4*20 bolt x 2



3.4 Shimano components

A. HP-NX10 Head parts of Shimano





Model No.	HP-NX10
A (mm)	ø29.85 - 30.0 or ø30.01 - 30.2
B (mm)	30.5 - 31.5
Front fork stem thread size	BC 1" X 24T.P.I
C (mm)	ø38 (max.)
D (mm)	21.7
Head tube material	Steel

B. SL-3S41E Shifting lever of Shimano



Series		NEXUS	Multi-Bearing Construction		-
Model no.		SL-3S41E	Shift lever bracket	Material	Resin
Color	1	-		Finish	Resin
	2	Black	Main lever body	Material	-
	3	-		Finish	-
Shifter type		REVOSHIFT	Release lever body	Material	-
Top-Normal		-		Finish	-
Speeds		3	Base cover	Material	Resin
Compatible internal geared hub type		NEXUS INTER-3		Finish	-
I-SPEC compatible		-	Shift lever cable	Material	Stainless steel
Shift lever position adjust		-		Finish	-
Shift lever cable adjust		-	Recommended shift lever Outer Casing		OT-SP40
Max. multiple shifts		2	Stainless clamp bolt		-
Release function	MULTI RELEASE	-	Brake lever integrated		-
	INSTANT RELEASE	-	Brake Lever Size		-
	2-WAY RELEASE	-	Left Hand Brake Lever		-
OPTICAL GEAR DISPLAY		Window	Clamping Diameter (mm)		22.2
LED Positioning Light		-	Note		

C. BR-T4000 V-Brake of Shimano



Spacer A position	Spacer B position	Graph area
Outside	Inside	X area
Inside	Outside	Y area


NOTE

- As with normal cantilever brakes, the Shimano V-BRAKE is designed for installation on frames with a 80 mm distance between bosses (center to center). Please refer to the graph for suitable rim width and boss distance combinations. If the brakes are used in conditions outside what is recommended, the brake performance may be adversely affected.
- Some rim width and boss combinations may require the reversal of A and B spacers in order to obtain the required $L1$ and $L2$ dimensions.
- If the L dimensions of the frame are too large, interference may be created between the riders legs and the brakes.
- To specify optimum set up and obtain the required minimum dimension L , refer to the graph above and the table below relating to boss distance, rim width, and spacer positioning.

4. Manual of EB Service interface


4.1 Resource introduction

A. EB Service interface




a. Menu :


- **Device** : You can select "Controller" to test the normality of your bike or update firmware of your system; "HMI" to set LCM contrast or update firmware of your HMI; "Battery" to check battery status of your bike.



- **Setting** : With this function you can re-install your PC diagnosis tool and select a new com port.



- About : The code of EB service interface version.



b. Test mode :

- Full test : With this selection, you can test the normality of the bike step by step, by the indications of EB service interface.
- Manual test : With this selection, you can test the normality of some particular functions manually.

c. Model information :

- Model ID : The code of bike's model.
- Model code : The code of bike's specification.
- Firmware version : The code of bike's firmware version (controller).

d. System Communication :

- If the communication between e-bike and PC are fine, then it will show "System connected", otherwise it shows "System disconnected".


e. The page of "Full test" :

- Testing standard version : The code of INI's file version.
- If you selected "Full test" function, the page will help you with instruction consequently to perform the full normality test of the bike.

f. Function information

- Items for test : This column tells which function items are for test.
- Value : This column tells the data which was read for test by PC diagnosis tool.
- Result : This column tells the judgment of each functions.
- Overall testing result : It tells the overall test result, if there is no error detected by PC diagnosis tool, then it will show "Pass".
- Print to file : After a cycle of test is finished, there will be a button to make file including testing data.

B. Diagnosis Tool



- a. Connect the HMI cable with your diagnosis tool.
- b. Connect the system cable with your diagnosis tool.
- c. Connect the diagnosis tool with your PC USB port.
- d. Show LED communication signal.
- e. Diagnosis tool switch to left with the HMI communication.
Diagnosis tool switch to right with the system communication.

4.2 Install program


✂ Introduction :

- If the program has never been executed in your PC, please follow the section 4.2.1 and 4.2.2 to install driver. After the successful installation, you can progress the updating by section 4.3.2 or 4.4.2.
- If the program had already been executed in your PC, please skip section 4.2.1 and 4.2.2.
- If the program had ever been executed successfully in your PC but fails now, please redo the section 4.2.1 and 4.2.2.

4.2.1 PL2303 driver setup


Note ! The version of driver should be later than v1.12.0

A. Right click the icon of the program, select "Properties" and go to the "Compatibility" tab.




- B. Set the compatibility of the programming tool to "Windows XP (Service Pack 3)".


Click "OK" and run the program.




- C. The Install Shield Wizard will be displayed to inform you that the PL-2303 USB-to-Serial driver will be installed on your computer. Click the "Next" button to continue.




D. The PL-2303 Driver Installer Program will then start to install the drivers needed.




E. Click the "Finish" button to close the Install Shield program.



- F. Re-plug the USB to Serial adapter to the PC USB port. Windows should be able to detect the driver. Go to "Device Manager" and check for the "Prolific USB-to-Serial Comm Port" device and the COM port number assigned by Windows.




- G. You can also confirm the driver version by right-clicking on the "Prolific USB-to-Serial Comm Port" device and select Properties and Driver tab.



Warning !


If there is still any trouble shown in "Device manager" in Windows XP or Windows 7, please save the screen photo and contact with Service center.




4.2.2 Component installer

- Install in Windows XP or Windows 7

A. Double click on "Component.bat".






B. After the program is installed into the system, the cmd option will be closed automatically.




● Install in Windows 10

- A. Copy all files in the Batch directory to "C:\Window2\System32" and "C:\Window2\SysWOW64".






B. Win10_Reg.bat → right click, and select "run as administrator" to register the files.



C. Press OK. (five files are registered successfully)



4.3 Controller

4.3.1 Connect to controller with Diagnosis tool


- A. Please turn off the power of the bike. (Press and hold power button at least 3 sec)




- B. Disconnect the connector between the HMI and controller. It's at the left side of the bike.




C. Connect your diagnosis tool with your PC.




D. Connect the system with your PC diagnosis tool; then PC diagnosis tool switch to the right.




- E. Execute the "EB service interface" in your PC. If you have already successfully installed your PC diagnosis tool, there will be a table showing and needing your selecting com port. (To know which port your PC diagnosis tool is relative to, you could check the Window's device program.)



- If no com port is available, it will show as below. Please try to well install your PC diagnosis tool and press OK. If this case always happens, please try another USB port of you PC, or change another PC.




- If it tries and fails for many times, the program will be closed.





4.3.2 Firmware update

A. Select "Device → Controller → Firmware update" to update firmware of your system.



B. After all the progresses of beginning are done, please press "confirm" button.

(Refer to 4.3.1)



- C. Connect the charger to the charge port on the bike to turn on the system.



- D. You can press [Get] button to check the current firmware version of the target device.



Device Information	
Model Code 3C6QK3L2	Model ID XB
Firmware Version 2.009	Device ID 257_4100
Get	

Bootloader Version	Get


- E. Press [Load] button () to import the firmware file.

Firmware File		
Model Code	Model ID	Firmware Version
Load-File Path		
Update		100%

- F. After loading the file, there will be a message to tell the hex file imported successfully or not.



- G. Select additional process that you want to execute after updating.



- H. Press [Update] button. At the same time, the "EB service interface" will try to acknowledge the adaption of default loader inside target device.


Firmware File

Model Code	Model ID	Firmware Version
3C6QK3L2	XB	2.010

Load-File Path
C:\en_eBike_v2.010_3C6QK3L2_XB.hex

Update 100%

EB Service Interface

 Connect Success, Update Firmware ?

[Controller]
=====

Model Code = 3C6QK3L2
Firmware Version = 2.009
Model ID = XB

[File]
=====

Model Code = 3C6QK3L2
Firmware Version = 2.010
Model ID = XB

Updating firmware will make device reset, continue ?

Yes No

- I. If the adaption is accepted, the updating progress will start and progress are showed as below.

The screenshot shows a software window with two main sections: "Device Information" and "Firmware File".

Device Information:

Model Code	3C6QK3L2	Model ID	XB	Get
Firmware Version	2.009	Device ID	257_4100	

Bootloader Version: 1.100 Get

Firmware File:

Model Code	3C6QK3L2	Model ID	XB	Firmware Version	2.010
------------	----------	----------	----	------------------	-------

Load-File Path: C:\en_eBike_v2.010_3C6QK3L2_XB.hex Folder icon

Stop 11%

A blue progress bar is shown below the "Stop" button, indicating 11% completion.

- J. If the progress is done completely, it will show message as follows.

The screenshot shows the same software window as in the previous image, but with a success message dialog box overlaid.

Device Information:

Model Code	3C6QK3L2	Model ID	XB
Firmware Version	2.009	Device ID	257_4100

Bootloader Version: 1.100

Firmware File:

Model Code	3C6QK3L2	Model ID	XB	Firmware Version	2.010
------------	----------	----------	----	------------------	-------


Load-File Path: C:\en_eBike_v2.010_3C6QK3L2_XB.hex Folder icon

Stop 100%

A blue progress bar is shown below the "Stop" button, indicating 100% completion.

Success Message Dialog:

EB Service Interface

 Update successfully and calibration done

OK

- K. After updating, you can press [Get] button to check the new firmware version of the target device, and it should be changed the same as updated file.

The screenshot shows a 'Device Information' form with the following fields and values:

Device Information	
Model Code	Model ID
3C6QK3L2	XB
Firmware Version	Device ID
2.010	257_4100

Bootloader Version	
1.100	

There are two 'Get' buttons: one next to the Model ID field (highlighted with a red rectangle) and one next to the Bootloader Version field.

- L. Separate the connectors from PC, and reconnect HMI and controller. Then disconnect the charger and turn off then turn on the system.

4.3.3 Monitor

Show the current status of the bike.

● Monitor

Motor Sensor Count

Pedal Sensor Count

Pedal RPM

Motor RPM

Torque (Nt · m)

Battery Voltage (V)

SOC (%)

☐ Brake

☐ Flat

☐ Pedal 1

☐ U Hall

☐ Pedal 2

☐ V Hall

☐ Speed Sensor

☐ W Hall

4.3.4 Sensor signal count

Accumulate value of the motor sensor or pedal sensor.

[Reset] button : Clear all of the accumulated value.

● Common Count

Reset

Motor Sensor Count

Pedal Sensor Count

Hall Sensor :

· Wrong Phase Count

· Wrong Combination Count

RPM Sensor :

· Wrong Phase Count

· Wrong Signal Interval Count

4.3.5 Wheel setup

[Get] button : Show previously saved wheel circumference.


[Set] button : Input the wheel circumference. (Please refer to "Wheel circumference list")

A dialog box titled "Wheel Setup" with a dark header. Below the header, there is a label "wheel (mm)" followed by a text input field. To the right of the input field are two buttons: "Get" and "Set".

Wheel Setup	
wheel (mm)	<input type="text"/>
	<input type="button" value="Get"/> <input type="button" value="Set"/>

4.3.6 Angle sensor calibration

Before you progress this function, please make sure the bike is put on the flat ground without pedaling.


A dialog box titled "Angle Sensor" with a dark header. Below the header, there is a message: "※ Before pressing the Calibrate button, please make sure the bike is put on the flat ground." At the bottom left, there is a button labeled "Calibrate".

Angle Sensor
※ Before pressing the Calibrate button, please make sure the bike is put on the flat ground.
<input type="button" value="Calibrate"/>

4.3.7 Toque sensor calibration

Calibrate the sensors of the bike.

While calibrating, "Do Not Pedal" to make sure calibrate correctly.

A button with the text "Torque Sensor Calibrate".

Torque Sensor Calibrate


✂ Wheel circumference list

ETRTO	Wheel size	Wheel circumference (mm)	ETRTO	Wheel size	Wheel circumference (mm)
	24 x 1-1/8 Tubular	1795	44-559	26 x 1.6	2051
	24 x 1-1/4	1905	47-559	26 x 1.75 x 2	2070
	24 x 1.75	1890	50-559	26 x 1.9	2089
	24 x 2.0	1925	54-559	26 x 2.00	2114
	24 x 2.15	1965	57-559	26 x 2.215	2133
	26 x 1 (559mm)	1913	37-590	26 x 1 3/8	2105
	26 x 1 (650c)	1952	37-584	26 x 1 3/8 x 1 1/2	2086
	26 x 1.25	1953	20-571	26 x 3/4	1954
	26 x 1-1/8 Tubular	1970	32-630	27 x 1 1/4	2199
	26 x 1-3/8	2068	28-630	27 x 1 1/4 fifty	2174
	26 x 1-1/2	2100	40-622	28 x 1.5	2224
	26 x 1.40	2005	40-622	28 x 1.75	2268
	26 x 1.50	1985	40-635	28 x 1 1/2	2265
	26 x 1.75	2023	37-622	28 x 1 1/8 x 1 5/8	2205
	26 x 1.95	2050		650 x 35A	2090
	26 x 2.0	2055		650 x 38A	2125
	26 x 2.1	2068		650 x 38B	2105
	26 x 2.15	2070	18-622	700 x 18c	2102
	26 x 2.35	2083	20-622	700 x 20c	2114
47-305	16 x 1.75 x 2	1217	23-622	700 x 23c	2133
47-406	20 x 1.75 x 2	1590	25-622	700 x 25c	2146
37-540	24 x 1 3/8a	1948	28-622	700 x 28c	2149
47-507	24 x 1.75 x 2	1907	32-622	700 x 32c	2174
23-571	26 x 1	1973	37-622	700 x 35c	2205
40-559	26 x 1.5	2026	40-622	700 x 40c	2224

4.3.8 Full test


In "full test mode", the "EB service interface" will help you the process to test the bike. The instructions may be different by models, so please carefully read the content listed, and follow the steps.

A. In the beginning of "Full test" mode, there are several process should be done.



B. After all the progresses of beginning are done, please press "confirm" button.

(Refer to 4.3.1)




- After that, the EB service interface will try to read basic information.

Model code	Model ID	Firmware version	System connected
3C6QK3L2	XB	2.010	

- If it fails, it will show some indication for you to fix it.

Model code	Model ID	Firmware version	System disconnected



C. After the confirmation of beginning process, the EB service interface will start to guide the test progress consequently. Each test item will give instructions and need to be followed with some easy manual operation. After judgment, the result of each item will be shown independently.

<div><div>Pedaling test 1</div><div>1. Please make sure the bike is on flat floor and put horizontally</div><div>Confirm</div><div>OK</div><div>Retry</div><div>Next</div><div>Return to beginning</div></div>	<div><div>Function information</div><table><tr><th>Items for test</th><th>Value</th><th>Result</th></tr><tr><td>Torque Sensor</td><td>0</td><td>OK</td></tr><tr><td>Other Sensor (Angle)</td><td>-1</td><td>OK</td></tr><tr><td>Clockwise Pedal Sensor Count</td><td></td><td></td></tr><tr><td>Clockwise RPM Sensor (Wrong Phase)</td><td></td><td></td></tr><tr><td>Clockwise RPM Sensor (Wrong Signal Interval)</td><td></td><td></td></tr><tr><td>Counterclockwise Pedal Sensor Count</td><td></td><td></td></tr><tr><td>Counterclockwise RPM Sensor (Wrong Phase)</td><td></td><td></td></tr><tr><td>Counterclockwise RPM Sensor (Wrong Signal Interval)</td><td></td><td></td></tr><tr><td>Speed Sensor Count</td><td></td><td></td></tr><tr><td>Hall Sensor (Wrong Phase)</td><td></td><td></td></tr><tr><td>Hall Sensor (Wrong Combination)</td><td></td><td></td></tr><tr><td>E-Brake</td><td></td><td></td></tr></table></div> <div><div>Overall testing result</div><div></div><div>Print to file</div></div>	Items for test	Value	Result	Torque Sensor	0	OK	Other Sensor (Angle)	-1	OK	Clockwise Pedal Sensor Count			Clockwise RPM Sensor (Wrong Phase)			Clockwise RPM Sensor (Wrong Signal Interval)			Counterclockwise Pedal Sensor Count			Counterclockwise RPM Sensor (Wrong Phase)			Counterclockwise RPM Sensor (Wrong Signal Interval)			Speed Sensor Count			Hall Sensor (Wrong Phase)			Hall Sensor (Wrong Combination)			E-Brake		
Items for test	Value	Result																																						
Torque Sensor	0	OK																																						
Other Sensor (Angle)	-1	OK																																						
Clockwise Pedal Sensor Count																																								
Clockwise RPM Sensor (Wrong Phase)																																								
Clockwise RPM Sensor (Wrong Signal Interval)																																								
Counterclockwise Pedal Sensor Count																																								
Counterclockwise RPM Sensor (Wrong Phase)																																								
Counterclockwise RPM Sensor (Wrong Signal Interval)																																								
Speed Sensor Count																																								
Hall Sensor (Wrong Phase)																																								
Hall Sensor (Wrong Combination)																																								
E-Brake																																								

- D. After each item was done, commonly there will be selections "Retry" and "Next" to decide repeat this test or keep going on.

Speed test

1. Turn the wheel foward slowly for 2 circles, then press "confirm" button

NG

Retry Next Return to beginning

Function information

Items for test	Value	Result
Torque Sensor	0	OK
Other Sensor (Angle)	-1	OK
Clockwise Pedal Sensor Count	37	OK
Clockwise RPM Sensor (Wrong Phase)	0	OK
Clockwise RPM Sensor (Wrong Signal Interval)	1	OK
Counterclockwise Pedal Sensor Count	0	OK
Counterclockwise RPM Sensor (Wrong Phase)	0	OK
Counterclockwise RPM Sensor (Wrong Signal Interval)	0	OK
Speed Sensor Count	0	NG
Hall Sensor (Wrong Phase)		
Hall Sensor (Wrong Combination)		
E-Brake		

Overall testing result

Print to file

- E. After a batch of test, there will be an "overall testing result" judging the normality of the whole bike.

Instruction

1. Please press the button of the bike or PC diagnosis tool for 3 seconds

2. Seperate the connector between system and PC diagnosis tool

3. Put the bike back to normally standing position

4. Connect the system with the HMI

Finish

Function information

Items for test	Value	Result
Torque Sensor	0	OK
Other Sensor (Angle)	-1	OK
Clockwise Pedal Sensor Count	37	OK
Clockwise RPM Sensor (Wrong Phase)	0	OK
Clockwise RPM Sensor (Wrong Signal Interval)	1	OK
Counterclockwise Pedal Sensor Count	0	OK
Counterclockwise RPM Sensor (Wrong Phase)	0	OK
Counterclockwise RPM Sensor (Wrong Signal Interval)	0	OK
Speed Sensor Count	0	NG
Hall Sensor (Wrong Phase)	1	OK
Hall Sensor (Wrong Combination)	0	OK
E-Brake	0	NG

Overall testing result

NG

Print to file

4.4 HMI

4.4.1 Connect to HMI with Diagnosis tool


- A. Please turn off the power of the bike. (Press and hold power button at least 3 sec)




- B. Disconnect the connector between the HMI and controller. It's at the left side of the bike.




C. Connect your diagnosis tool with your PC.




D. The PC diagnosis tool is connected with a turning cable to one the end of the cable of HMI and the other one is connected with a turning cable to the end of the cable of system which is provided battery power; then PC diagnosis tool switch to the left.




- E. Execute the "EB service interface" in your PC. If you have already successfully installed your PC diagnosis tool, there will be a table showing and needing your selecting com port. (To know which port your PC diagnosis tool is relative to, you could check the Window's device program.)



- If no com port is available, it will show as below. Please try to well install your PC diagnosis tool and press OK. If this case always happens, please try another USB port of you PC, or change another PC.




- If it tries and fails for many times, the program will be closed.





4.4.2 Firmware update

A. Select "Device → HMI → Firmware update" to update firmware of your HMI.



B. After all the progresses of beginning are done, please press "confirm" button.

(Refer to 4.4.1)




C. Connect the charger to the charge port on the bike to turn on the system.





D. You can press [Get] button to check the current firmware version of the target device.

Device Information	
Model Code	Model ID
<input type="text"/>	<input type="text" value="00"/>
Firmware Version	Device ID
<input type="text" value="255.255"/>	<input type="text" value="128_4101"/>
<hr/>	
Bootloader Version	
<input type="text"/>	
<div>Get</div>	


E. Press [Load] button () to import the firmware file.

Firmware File		
Model Code	Model ID	Firmware Version
<input type="text"/>	<input type="text"/>	<input type="text"/>
Load-File Path		
<input type="text"/>		
<div>Update</div>		<div></div>
		100%
<input type="text"/>		

F. After loading the file, there will be a message to tell the hex file imported successfully or not.



- G. Press [Update] button. At the same time, the "EB service interface" will try to acknowledge the adaption of default loader inside target device.




The "Firmware File" dialog box contains the following fields and controls:

Model Code	Model ID	Firmware Version
VHCC20G5		2.002

Load-File Path
C:\en_HMI_v2.002_VHCC20G5.hex

[Update] 100%



The "EB Service Interface" dialog box displays the following information:

Connect Success, Update Firmware ?

[Controller]
=====

Model Code =
Firmware Version = 255.255
Model ID = 00

[File]
=====

Model Code = VHCC20G5
Firmware Version = 2.002
Model ID =

Updating firmware will make device reset, continue ?

[Yes] [No]

- H. If the adaption is accepted, the updating progress will start and progress are showed as below.

The screenshot shows the EB Service Interface with two main sections: **Device Information** and **Firmware File**.

Device Information:

- Model Code:** [Empty text box]
- Model ID:** [00] [Get]
- Firmware Version:** [255.255]
- Device ID:** [128_4101]
- Bootloader Version:** [1.100] [Get]

Firmware File:

- Model Code:** [VHCC20G5]
- Model ID:** [Empty text box]
- Firmware Version:** [2.002]
- Load-File Path:** [C:\en_HMI_v2.002_VHCC20G5.hex] [Folder icon]
- Stop:** [Stop button]
- Progress:** [Blue progress bar] 11%

- I. If the progress is done completely, it will show message as follows.

The screenshot shows the EB Service Interface with the same sections as before, but the progress bar is now at 100%.

Device Information:

- Model Code:** [Empty text box]
- Model ID:** [00]
- Firmware Version:** [255.255]
- Device ID:** [128_4101]
- Bootloader Version:** [1.100]

Firmware File:

- Model Code:** [VHCC20G5]
- Model ID:** [Empty text box]
- Firmware Version:** [2.002]
- Load-File Path:** [C:\en_HMI_v2.002_VHCC20G5.hex] [Folder icon]
- Stop:** [Stop button]
- Progress:** [Blue progress bar] 100%

Success Message Dialog:

EB Service Interface

Update successfully and calibration done

[OK]

- J. After updating, you can press [Get] button to check the new firmware version of the target device, and it should be changed the same as updated file.

The screenshot shows a 'Device Information' window with the following fields and buttons:


Device Information	
Model Code VHCC20G5	Model ID
Firmware Version 2.002	Device ID 128_4101
<hr/>	
Bootloader Version 1.100	

There are two 'Get' buttons: one next to the Model ID field (highlighted with a red rectangle) and one next to the Bootloader Version field.

- K. Separate the connectors from PC, and reconnect HMI and controller. Then disconnect the charger and turn off then turn on the system.

4.4.3 LCD setting


Calibrate the HMI screen contrast.



4.5 Battery


With "battery function" of it will help you check the battery of bike. The instructions may be different by models, so please carefully read the content listed, and follow the steps.

A. In the beginning of "Battery" function, there are several process should be done.




B. After all the progresses of beginning are done, please press "confirm" button.

(Refer to 4.3.1)



- After that, the EB service interface will try to read information. If it fails, it will show some indication for you to fix it.



C. There are 3 major categories of battery information listed by this function.

"Product information" tells the basic specification and producing data.

"Status" shows the current condition of battery to confirm the normality of battery.

"Record" lists important event which was memorized inside the battery.

With this information, the normality of battery's usage can be traced and confirmed.

- Product information

[Date and time modify] button : modify the battery's date and time.

Product information		Status	Record
Item	Value		Date and time modify
MCU firmware version	0.2.012		
Company name	34		
Model name	5678		
Cell brand	9		
PCBA version	A		
Manufacture year	2015		
Manufacture week	4		
Serial number	13141516		
Design capacity (mAh)	11000		
Design voltage (V)	36		System connected
Gauge firmware version			

Error code

- ☐ OCD (Over Current Discharge)
- ☐ SCD (Short Circuit Discharge)
- ☐ OV (Over Voltage)
- ☐ UV (Under Voltage)
- ☐ OTD (Over Temperature Discharge)
- ☐ OTC (Over Temperature Charge)
- ☐ UTD (Under Temperature Discharge)
- ☐ UTC (Under Temperature Charge)

Error protection

- ☐ OW (Open Wire)
- ☐ CU (Cell Unbalance)
- ☐ OCC (Over Current Charge)

● Status

Product information		Status	Record		System connected	
Item	Value		Item	Value		
Date and time	2017/11/28 12:35:05		Cell 01 voltage (mV)	4199	Error code <input type="checkbox"/> OCD (Over Current Discharge) <input type="checkbox"/> SCD (Short Circuit Discharge) <input type="checkbox"/> OV (Over Voltage) <input type="checkbox"/> UV (Under Voltage) <input type="checkbox"/> OTD (Over Temperature Discharge) <input type="checkbox"/> OTC (Over Temperature Charge) <input type="checkbox"/> UTD (Under Temperature Discharge) <input type="checkbox"/> UTC (Under Temperature Charge)	
Status	Stand By		Cell 02 voltage (mV)	4204		
Cell balance status	Unbalance		Cell 03 voltage (mV)	4205		
Sleep status	Disable		Cell 04 voltage (mV)	4202		
Charging flag	Discharging (Not Plug)		Cell 05 voltage (mV)	4206		
Inrush MOSFET	OFF		Cell 06 voltage (mV)	4203		
SOC (%)	100		Cell 07 voltage (mV)	4203		
Voltage (V)	42.28		Cell 08 voltage (mV)	4208		
Current (A)	0		Cell 09 voltage (mV)	4205		
Temperature (°C)	23		Cell 10 voltage (mV)	4207		
Remaining capacity (mAh)	10810		Cell 11 voltage (mV)	0	Error protection <input type="checkbox"/> OW (Open Wire) <input type="checkbox"/> CU (Cell Unbalance) <input type="checkbox"/> OCC (Over Current Charge)	
Full charge capacity (mAh)	10810		Cell 12 voltage (mV)	0		
Cycle count	37		Cell 13 voltage (mV)	0		
			Cell 14 voltage (mV)	0		
			Cell 15 voltage (mV)	0		
			Cell 16 voltage (mV)	0		

● Record


Product information		Status	Record	System connected	
Item	Value				
Over voltage protection counts in charge	0			Error code <input type="checkbox"/> OCD (Over Current Discharge) <input type="checkbox"/> SCD (Short Circuit Discharge) <input type="checkbox"/> OV (Over Voltage) <input type="checkbox"/> UV (Under Voltage) <input type="checkbox"/> OTD (Over Temperature Discharge) <input type="checkbox"/> OTC (Over Temperature Charge) <input type="checkbox"/> UTD (Under Temperature Discharge) <input type="checkbox"/> UTC (Under Temperature Charge)	
OV protection date and time	2000/00/00 00:00:00				
Under voltage protection counts in discharge	0				
UV protection date and time	2000/00/00 00:00:00				
OCD protection counts in discharge	0				
OCD date and time	2000/00/00 00:00:00				
SCD protection counts in discharge	207				
SCD date and time	2017/10/25 17:06:12				
Over temperature protection counts in charge	0				
OTC protection date and time	2000/00/00 00:00:00				
Over temperature protection counts in discharge	0			Error protection <input type="checkbox"/> OW (Open Wire) <input type="checkbox"/> CU (Cell Unbalance) <input type="checkbox"/> OCC (Over Current Charge)	
OTD protection date and time	2000/00/00 00:00:00				
Under temperature protection counts in charge	1				
UTC protection date and time	2015/05/07 09:24:21				
Under temperature protection counts in discharge	0				
UTD protection date and time	2000/00/00 00:00:00				
Power on counts	30331				
Last power on date and time	2017/11/28 12:30:59				
Charge counts (more than 60s)	344				
Last charge date and time	2017/11/28 12:14:04				
Full charge counts (to 100%)	30071				
The days since last full charge	2017/11/28 12:30:59				
2nd protection active date and time	N.A.				

5. Trouble shooting

5.1 Error or warning alert

- Error code

Code	Description	Action
E01	Motor is stalled	<p>Please carry the bike forward manually.</p> <p>If there is obvious obstruction, please change the motor.</p> <p>If it is smooth, please change the motor or controller to verify which parts is failed.</p>
E02	Speed sensor is abnormal	<p>Turn off the system and make sure the connectors connected well between the controller and motor.</p> <p>Turn on and do the riding test.</p> <p>If the error still occurs, please change the motor or controller to verify which parts is failed.</p>
E04	The communication between controller and battery fails while power on	<p>Generally it will be recovered automatically.</p> <p>If it happens frequently, please turn off the system, then remove the battery and check both connectors on the bike and battery.</p> <p>Install the battery and turn on the system.</p> <p>If the error occurs, please check the metal pin priority, and then update the HMI firmware.</p> <p>If the error still occurs, please change the battery or controller.</p>
E05	Motor is driving hard	<p>If it happens seldom while the bike is climbing uphill, it should be a normal protection.</p> <p>However if it always happens on flat road, please change motor or controller to verify which parts is failed.</p>

Code	Description	Action
E06	Battery report error	Turn off then turn on the system. If the error still occurs, please change the battery.
E07	Torque value is abnormal	Turn off then turn on the system. If the error still occurs, please change the torque sensor or controller to verify which parts is failed.
E08	Torque initial value is abnormal	Turn off then turn on the system. If the error still occurs, please refer to the technical manual and use PC service interface to calibrate the torque sensor.
E09	Temperature is too high in the controller	Please turn off the system and wait for 60 minutes to cool down the system. Turn on the system, if the error still occurs, please change the controller.
E10	Voltage is too high in the controller	Turn off then turn on the system. If the error still occurs, please remove the battery measure the voltage. If the voltage is more than 42V, please change the battery, else please change the controller. (Different types of battery may have different appearance, please refer the (+) pin and (-) pin definition below) 
E11	Voltage is too low in the controller	Please charge the battery with the charger until battery is fully charged. If the error still occurs, please change the controller.

Code	Description	Action
E12	Current is too large in the controller	Turn off then turn on the system. If the error still occurs, please change the controller.
E16	Halls' arrangement is mismatch	Turn off the system and make sure the connectors connected well between controller and motor, then turn on. If the error still occurs, please change motor or controller to verify which parts is failed.
E57	The communication between HMI and controller fails.	Turn off then turn on the system. If the error still occurs, please change the HMI or controller to verify which parts is failed.
E82	Battery is OW (Open Wire) protection	Turn off then turn on the system. If the error still occurs, please change the battery.
E83	Battery is CU (Cell Unbalance) protection	Turn off then turn on the system. If the error still occurs, please change the battery.
E84	Battery is OCC (Over Current Charge) protection	Turn off then turn on the system. If the error still occurs, please change the battery.



- Warning code

Code	Description	Action
W01	The communication between the controller and battery is not stable.	<p>Generally it will be recovered automatically.</p> <p>If it happens frequently, please update the HMI with firmware (version 2.004S2 or higher), and replace a HMI with hardware (version 2.0 or higher).</p> <p>If no, please replace the HMI and update to new version firmware.</p> <p>Please remove the battery, and confirm the metal pin was drawn back or not.</p> <p>If yes, please change the abnormal parts.</p> <p>Install the battery and turn on the system.</p> <p>If the error still occurs, please change the battery or controller.</p>
W02	Motion sensor of controller fails	<p>Generally it will be recovered automatically.</p> <p>If it happens frequently, please update the HMI with firmware (version 2.004S2 or higher).</p> <p>If no, please update to new version firmware.</p> <p>Install the battery and turn on the system.</p> <p>If the error still occurs, please change the controller.</p>
W03	The assistance is limited because of controller's temperature	<p>The system can still work, but the power may be limited. You can keep using it, or turn off the assistance and wait for 30 minutes until the system cool down.</p> <p>If the warning still occurs after more than 2 hours, please change the controller.</p>


5.2 Procedure

Issue	Step	Check step	Action
No assistance while pedaling.	1	Check if the assistant level is 0 or not.	If yes, please adjust the assistant level ≥ 1 . If no, please progress the next step.
	2	Check if the connectors between motor and controller connect well or not.	If yes, please progress the next step. If no, please turn off the system and reconnect the motor's cable.
	3	Connect the diagnosis tool to the system and execute the "EB Service Interface". Use the "Manual test" function with technical manual. Rotate the wheel backwards manually and monitor the "U hall", "V hall" and "W hall" check-boxes. All of the hall sensor check-boxes shouldn't be the same. (checked or non-checked) While rotating, the check-boxes should keep changed at the same time. (checked or non-checked)	If yes, please progress the step 6. If no, please progress the next step.
	4	Replace the standard controller, and check the result again after repeating the progress of step 3.	If yes, please replace the controller. If no, please replace the motor.
	5	Connect the diagnosis tool to system. Rotate the pedal forwards manually, and the "pedal 1", "pedal 2" signals should keep changed, and "RPM" should show value.	If yes, please contact with the manufacturer. If no, please progress the next step.
	6	Replace the standard controller, and check the result again after repeating the progress of step 5.	If yes, please replace the controller. If no, please replace the pedaling sensor.

Issue	Step	Check step	Action
Power outputs while pedaling backwards.	1	Connect the diagnosis tool to system and execute the "EB Service Interface". Choose "Manual test". Rotate the pedal backwards manually, and check if the "Pedal Sensor Count" text-box >1.	If yes, please progress the next step. If no, please contact with the manufacturer.
	2	Replace the standard controller, and check the result again after repeating the progress of step 1.	If yes, please replace the controller. If no, please replace the pedaling sensor.
The assistance level resets to 0 while pedaling.	1	Check if the connectors between motor and controller connect well or not.	If yes, please progress the next step. If yes, please turn off the system and reconnect the motor's cable.
	2	Check if there any damage in motor cable.	If yes, please replace the motor. If no, please progress the next step.
	3	Connect the diagnosis tool to system and execute the "EB Service Interface". Choose "Manual test". Rotate the wheel backwards manually and monitor the "U hall", "V hall" and "W hall" check-boxes. All of the hall sensor check-boxes shouldn't be ticked or non-ticked at the same time, and should keep being ticked or non-ticked while rotating.	If yes, please progress the next step. If no, please replace the motor.
	4	Replace the standard motor and check the normality again.	If yes, please progress the next step. If no, please replace the motor.
	5	Replace the standard controller and check the normality again.	If yes, please contact with the manufacturer. If no, please replace the controller.

Issue	Step	Check step	Action
The assistance is not smooth and discontinuous while pedaling.	1	<p>Connect the diagnosis tool to system and execute the "EB Service Interface".</p> <p>Choose "Device → Firmware update".</p> <p>Check the "Firmware Version" text-box is correct or not.</p>	<p>If yes, please progress the next step.</p> <p>If no, please upgrade the firmware of controller.</p>
	1.1	<p>1. Please check if the sensor cable of controller near the rear carrier is encircled and equipped with EMI core.</p>  <p>2. Please check if the torque sensor's cable inside the motor box is equipped with EMI core. The EMI core should be fixed with cable ties.</p> 	<p>If yes, please progress the next step.</p> <p>If no, please install EMI core.</p>

Issue	Step	Check step	Action
The assistance is not smooth and discontinuous while pedaling.	2	Connect the diagnosis tool to system and execute the "EB Service Interface". Choose "Manual test". Rotate the pedal forwards manually, and the "pedal 1", "pedal 2" check-boxes should keep being ticked or non-ticked and "Pedal RPM" text-box should show value.	If yes, please progress the step 4. If no, please progress the next step.
	3	Replace the standard controller and check the normality again.	If yes, please replace the controller. If no, please replace the pedaling sensor.
	4	Connect the diagnosis tool to system and execute the "EB Service Interface". Choose "Manual test". The initial value of "Pedal Sensor Count" check-box should be 0 or 1. Rotate the pedal forwards manually for 2 circles, and check if the "Pedal Sensor Count" text-box is 31 ~ 33 or not.	If yes, please progress the next step. If no, please replace the pedaling sensor.
	4.1	Connect the diagnosis tool to system and execute the "EB Service Interface". Choose "Manual test". Please do the "Calibrate". After the calibration, the "Torque (Nt.m)" text-box should be 0 or 1. While stamping is on both pedals, the "Torque (Nt.m)" text-box should increase.	If yes, please contact with the manufacturer. If no, please replace the torque sensor.
After turning on system, the HMI is on but can't be operated.	1	Replace the standard HMI and check the normality.	If yes, please replace the HMI. If no, please replace the controller.

Issue	Step	Check step	Action
The HMI immediately turns off after turning on.	1	Replace the standard HMI and check the normality again.	If yes, please replace the HMI. If no, please contact with the manufacturer.
The system can't be turned on or HMI can't be on.	1	Remove the battery, please make the meter's probe (+) contact to battery metal pin (+), and the meter's probe (-) contact to battery metal pin (-), check it is lower than 30V or not. 	If yes, please progress the next step. If no, please progress the step 3.
	1.1	Push the indicator button on battery and check the capacity is 0 or any protection displayed.	If yes, please progress the next step. If no, please progress the step 3.
	2	Charge the battery with charger and the led indicator on charger should work normally.	If yes, please charge the battery fully then test again. If no, please replace the battery.
	3	Replace the standard battery and check the normality again.	If yes, please replace the battery. If no, please progress the next step.
	4	Replace the standard HMI and check the normality again.	If yes, please replace the HMI. If no, please contact with the manufacturer.